

CE 107403575 B



INSTRUCTIONS FOR USE

VU500 12 INCH SMU US

VU500 15 INCH SMU US



Contents

1	Important safety instructions.....	03
1.1	<i>Symbols used to mark instructions</i>	<i>03</i>
1.2	<i>Warnings.....</i>	<i>03</i>
1.3	<i>Grounding instructions.....</i>	<i>04</i>
2	Introduction	05
2.1	<i>Operating elements and accessories</i>	<i>05</i>
2.2	<i>Instructions for use</i>	<i>06</i>
2.3	<i>Purpose and intended use.....</i>	<i>06</i>
2.4	<i>Further support</i>	<i>06</i>
2.5	<i>Before use</i>	<i>06</i>
3	Before starting the cleaner.....	07
3.1	<i>Setting up the cleaner.....</i>	<i>07</i>
4	Control / Operation.....	08
4.1	<i>Operating the vacuum cleaner</i>	<i>08</i>
4.2	<i>Clearing a clog</i>	<i>09</i>
4.3	<i>Using the wand (optional)</i>	<i>10</i>
4.4	<i>Using the tools (optional)</i>	<i>11</i>
5	Maintenance.....	12
5.1	<i>Changing the paper dust bag</i>	<i>12</i>
5.2	<i>Emptying the cloth dust bag</i>	<i>14</i>
5.3	<i>Changing or cleaning of the brush.....</i>	<i>14</i>
5.4	<i>Filters - type of filter may vary from different models.....</i>	<i>15</i>
5.5	<i>Changing the HEPA-filter.....</i>	<i>16</i>
5.6	<i>Cleaning or changing the pre-filter.....</i>	<i>17</i>
6	After using the cleaner	18
6.1	<i>Switching off the cleaner.....</i>	<i>18</i>
7	Further information	19
7.1	<i>Repair and maintenance.....</i>	<i>19</i>
7.2	<i>Guarantee.....</i>	<i>19</i>
7.3	<i>Specifications.....</i>	<i>19</i>

1 Important safety instructions

1.1 Symbols used to mark instructions

DANGER



- Danger that leads directly to serious or irreversible injuries, or even death.

WARNING



- Danger that can lead to serious injuries or even death.

CAUTION



- Danger that can lead to minor injuries and damage.

1.2 Warnings



WARNING


- To reduce the risk of fire, electric shock, or injury. Do not leave the appliance when it is plugged in. Unplug the unit from the outlet when not in use and before servicing.
- To reduce the risk of electric shock, do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only the manufacturer's recommended attachments.
- If the appliance is not working as it should be, has been dropped, damaged, left outdoors or dropped into water, return it to a service center. The machine must not be used if the electrical cord shows any sign of damage. Regularly inspect the cord for damage, particularly if it has been crushed, shut in a door or run over.
- Do not pull or carry by the cord, use the cord as a handle, or pull the cord around sharp edges or corners. Keep the cord away from heated surfaces.
- Do not unplug by pulling on the cord. To unplug, grasp the plug, not the cord.
- Do not handle the plug, cord or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked.
- Keep loose clothing, hair, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes or matches. Under no circumstances should the machine be used for picking up hot material. In particular the machine must not be used for cleaning open and closed fireplaces, ovens or similar that contain warm or glowing ashes.
- Do not use without dust bag and/or filters in place.
- Turn off all controls before unplugging. The plug must always be removed from the socket outlet before starting any service or repair work of the vacuum cleaner or the cord.
- Avoid vacuuming hard or sharp objects.
- Use extra care when cleaning on stairs.
- The machine must not be used for picking up combustible materials which are health endangering or explosive materials such as petrol (gasoline), nor should it be used in an explosive atmosphere. The machine must not be used for picking up water, other liquids or for picking up hazardous - i.e. poisonous dust.
- The machine is not designed for picking up hazardous - i.e. poisonous dust.



WARNING

- No changes or modifications of the mechanical, electrical or thermal safety devices should be made.
- When repairing or replacing the cord, the same type of cord as originally supplied with the machine must be used.
This cord can be supplied by ADVANCE.

SAVE THESE INSTRUCTIONS



1.3 Grounding instructions

This appliance must be grounded. If it should electrically malfunction, grounding provides a path of least resistance for electric current to reduce the risk of electric shock. This appliance is equipped with a cord having an equipment-grounding conductor and grounding plug. The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.



DANGER

Improper connection of the equipment-grounding conductor can result in a risk of electric shock. Check with a qualified electrician or service person if you are in doubt as to whether the outlet is properly grounded. Do not modify the plug provided with the appliance. If it will not fit the outlet, have a proper outlet installed by a qualified electrician.

This appliance is for use on a nominal 120-volt circuit, and has a grounding plug that looks like the plug illustrated in Figure 1 below. A temporary adapter illustrated in Figures 2 and 3 may be used to connect this plug to a 2-pole receptacle as shown in Figure 2 if a properly grounded outlet is not available. The temporary adapter should be used only until a properly grounded outlet (Figure 1) can be installed by a qualified electrician.

The green-colored rigid ear, tab, or the like extending from the adapter must be connected to a permanent ground such as a properly grounded outlet box cover. Whenever the adapter is used, it must be held in place by a metal screw. Grounding adapters are not approved for use in Canada.


Replace the plug if the grounding pin is damaged or broken.

The Green (or Green/Yellow) wire in the cord is the grounding wire. When replacing a plug, this wire must be attached to the grounding pin only.

Extension cords connected to this machine should be 12 gauge, three-wire cords with three-prong plugs and outlets.

DO NOT use extension cords more than 50 feet (15 meter) long.

PLEASE NOTE: FOR NORTH AMERICA ONLY




2 Introduction

2.1 Operating elements and accessories

As you read this manual, you will occasionally run across a bold number in parentheses - example: (2). These numbers refer to an item shown on this page. Refer back to this page whenever necessary, to pinpoint the location of an item mentioned in the text.

- | | |
|--------------------|--------------------------------|
| 1. Handle | 8. Wand |
| 2. Cord Hook | 9. Crevice Tool |
| 3. Vacuum Hose | 10. "Restricted Airflow Light" |
| 4. Dust lid | 11. Dust lid button |
| 5. Carrying Handle | 12. Main Power Switch |
| 6. Brush Housing | 13. Exhaust Filter Cover |
| 7. Pedal | 14. Power Cord Clamp |



2.2 Instructions for use



This manual will help you get the most from your Advance vacuum cleaner.

Prior to using the appliance for the first time, be sure to read this document through and keep it ready to hand.

Besides the operating instructions and the binding accident prevention regulations valid in the country of use, observe recognised regulations for safety and proper use.

RATING PLATE

The Model Number and Serial Number of your machine are shown on the rating plate on the machine.

This information is needed when ordering spare parts for the machine.

Use the space below to note the Model

Number and Serial Number of your machine for future reference.

MODEL NUMBER _____

SERIAL NUMBER _____

2.3 Purpose and intended use

This machine is for commercial use, for example in hotels, schools, hospitals, factories, shops and offices other than normal residential housekeeping purposes.

Any other use is considered as improper use. The manufacturer accepts no liability for any damage resulting from such use. The risk for such use is borne solely by the user. Proper use also includes proper operation, servicing and repairs as specified by the manufacturer.

**THIS APPLIANCE IS INTENDED FOR DRY USE ONLY!
DO NOT USE FOR WET FLOOR OR CARPET!**

2.4 Further support

For further queries, please contact the Nilfisk service representative responsible for your country or visit our web site;
www.nilfisk-advance.com

2.5 Before use

Before starting up your machine, please check it carefully for any defects. If you find any, do not start up your machine.

- When the machine is delivered, carefully inspect the shipping carton and the machine for damage.
- If damage is evident, save the shipping carton so that it can be inspected.
Contact the Advance Customer Service Department immediately to file a freight damage claim.

USA:

Nilfisk-Advance Inc. 14600 21st Avenue North, Plymouth,
MN 55447-3408, Tel.: (763) 745 3500

Canada:

Nilfisk-Advance Canada, 240 Superior Boulevard, Mississauga,
Ontario, L5T 2L2, Tel.: 905-564-1149

3 Before starting the cleaner

3.1 Setting up the cleaner



1. Carefully take out the vacuum cleaner from its carton.
2. Insert the handle at the opening at the top of the bag housing. Push the button to secure the handle in place.
3. Mount the plug into the machine socket.



4. Mount the wand and hose as shown.



CAUTION

- Foot pedal must be used to release base to operating/non operation position. Failure to do so could result in damage to the release mechanism.




4 Control / Operation

4.1 Operating the vacuum cleaner



1. Engage the carabine function to release the cord.
2. Ensure the cord is looped and locked in the restraint clip.
3. Turn the Main Power Switch (12) ON. "I" is ON and "O" is OFF. Now the vacuum motor will start.
4. Step on the Pedal (7) and then tilt the cleaner backwards. The brush is always turning when on.





CAUTION

- Foot pedal must be used to release base to operating/non operation position. Failure to do so could result in damage to the release mechanism.



WARNING

- Always disconnect the power cord before performing any machine maintenance.

Whenever (10) “Restricted Airflow Light” indicator comes on, check the following: Is the bag full and needs to be changed or is the tube, hose or nozzle blocked.

For details of dust bag replacement see separate instruction in this manual. If the light comes on before the bag is full, the inside of the bag may be coated with very fine dust (change the bag), or debris may have clogged the hose between the brush and the bag.

4.2 Clearing a clog

First remove the upper hose and wand, and inspect them for clogged debris. Then detach the wand receptacle by pulling at it. It will lay flat on the floor, connected to the base hose.

Release and remove the brush cover and brush as described on page 14. Now inspect the lower hose, looking through it from the wand receptacle to the brush housing area. You should be able to see clear through it. If you can't there is probably debris clogged in it. You may remove the debris by pushing it forward to the brush opening with a long narrow object, such as a ruler or screw driver. Pull the debris out from the brush housing opening until you can see clearly through the hose.

Once the clog is cleared, replace the brush and brush cover. Then re-attach the wand receptacle, which clicks into place.

4.3 Using the wand (optional)



1. Push the machine to upright locked position. The brush will be lifted up from the surface. Then slide the wand out of its holder.



2. Use the wand for cleaning hard to reach places like floor corners, or furniture.



CAUTION

- Foot pedal must be used to release base to operating/non operation position. Failure to do so could result in damage to the release mechanism.



4.4 Using the tools (optional)



1. The crevice tool is placed in the lower section of the cleaner.
2. Install the Crevice Tool or Upholstery Tool on the end of the Wand, or on the end of the hose, which can be detached from the wand, if desired. Now the vacuum cleaner will have an extended coverage performance and can be used for cleaning hard to reach areas like roof strips, or furnitures.


These tools are not standard items in all machine variants. Use these tools for a better cleaning performance at hard to reach areas. A Crevice Tool (9) is placed conveniently on the machine, just behind the wand.

Remove the wand from the vacuum cleaner and you will have free access to the Tools.



CAUTION

- Foot pedal must be used to release base to operating/non operation position. Failure to do so could result in damage to the release mechanism.



5 Maintenance



WARNING

- Always disconnect the power cord before performing any machine maintenance.

5.1 Changing the paper dust bag


Change the bag whenever the “Bag Full” (10) indicator comes on. To replace the Paper Dust Bag:



1. Disconnect the power cord from the electrical outlet. Pull the Dust lid button (11).




2. Remove the Dust lid outwards to remove it from the cleaner.



3. Push downwards at the edge to the left of the plastic holder, so that the bag loosens from the vacuum inlet of the machine.





4. Grasp at the cardboard piece of the bag and gently pull the full bag outwards - away from cleaner.

5. Insert a new paper dust bag into the slot of the bag holder and push the bag in place. Check so that the paper dust bag not is jammed in the holder. Only the cardboard piece of the bag should be attached to the bag holder.



6. Push the bag holder with the new bag upwards, so that the bag inlet fastens to the inlet of the machine. Make sure that the bag is unfolded and will fit in place in the bag housing. Also check that the "no bag" clip is placed to the left so that the lid will be able to close.



7. Fit the two notches of the back cover to the two slots at the lower part of the bag housing, and push the back cover back in place at the housing.

5.2 Emptying the cloth dust bag

Empty the Bag whenever the "Bag Full" Light (10) comes on. To empty or to replace:

1. Remove cloth bag as above in steps 1-3.
Disconnect the power cord from the electrical outlet. Pull the Dust lid button (11) and remove the Dust lid outwards to remove it from the cleaner.
2. Push downwards at the edge to the left of the plastic holder, so that the bag loosens from the vacuum inlet of the machine.
3. Grasp at the plastic flange of the bag and gently pull the bag outwards - away from cleaner.
4. Remove bag clip and shake out bag contents.
5. Put the bag clip back on the bag.
6. Replace clean/new cloth bag into machine and close back cover as above in step 4-6. Insert the cleaned/new cloth bag into the slot of the bagholder and push the bag in place so that bag is secured.
7. Push the bag holder with the new bag upwards, so that the bag inlet fasten to the inlet of the machine. Make sure that the bag is unfold and will fit in place at the bag housing. Also check that the "no bag" clip is placed to the left so that the lid will be able to close.
8. Fit the two notches of the back cover to the two slots at the lower part of the bag housing, and push the back cover back in place at the housing.



CAUTION

- Photos shows changing of the paper dust bags!
Never operate the machine without a Dust Bag in place.

5.3 Changing or cleaning of the brush




WARNING

- Always disconnect the power cord before performing any machine maintenance.



1. Unplug the power cord from the electrical outlet.
2. Release the brush roller by unlocking the bearing block. Push the button down towards the unlocking symbol at the brush housing.




3. Grasp at the bearing block and pull it out from the brush housing.



4. Remove the used brush.
5. Replace the used brush roller with a new one, or clean and remove all debris from the present brush.



6. Slide back the brush into the the fixed bearing block in the brush house.



7. Push the bearing block in its position. Lock it by turning clockwise.

5.4 Filters - type of filter may vary from different models

On these machines there are two different filters; one pre-filter before the vacuum motor and one exhaust filter.

There are two different types of exhaust filters available to these machines, HEPA-filter and a standard exhaust filter. The HEPA-filter (High Efficiency Particulate Air filter) offers better filtration capacity than the standard exhaust filter. The exhaust filters catches any dirt that may escape from the dust bag, or motor pre filter. Replace the motor pre filter every 5th time that the dust bag is changed (more often in very dusty applications). The exhaust filters are located at the front side of the machine just above the brush base.

The HEPA filter can not be cleaned or washed clean. When the HEPA-filter is clogged it must be replaced. Replace the exhaust / HEPA filter 1-2 times per year depending on amount of use.

5.5 Changing the HEPA-filter



1. Disconnect the power cord from the electrical outlet. Push the Filter Cover Latch (13) downwards so that the cover is released. Remove the filter cover from cleaner.



2. Grasp at the filter frame and remove the used and dirty HEPA-filter.



3. Grasp at the filter frame and then insert the new HEPA filter to the cleaner by pushing it in place. (Never touch the filter media of a HEPA-filter! Doing so may cause a loss of performance of the HEPA-filter).



4. Snap the Filter Cover back in place at the cleaner.



CAUTION

- Never operate the cleaner without the HEPA-Filter in place in the machine. These machines are not designed for picking up hazardous - i.e. poisonous dust!

5.6 Cleaning or changing the pre-filter

The pre filter catches any dirt spilled from the bag, before it can enter the vacuum motor. The filter is located below the bag. Clean or replace motor pre filter every 5th time that the bag is changed. (more often in very dusty applications).



1. Disconnect the power cord from the electrical outlet. Then push the Dust lid button (11) in and remove the dust lid (4).



2. Grasp at the filter holder and pull the holder out from the Dust compartment.

3. Remove the dirty filter from the filter holder and replace with a new pre filter. The pre filter may also be washed. Wash it in warm water. Let the filter dry completely before putting it back into the filter holder.



4. This machine is also equipped with a deodorizer pad. It's located in the pre filter holder. Replace it to a new deodorizer pad when the function begins to fade.

5. Put back the new/washed filter into the holder. Then put back the holder with filter in place in the bag housing.



6. Fit the two notches of the back cover to the two slots at the lower part of the bag housing, and push the back cover back in place at the housing.



WARNING

- Never operate the machine without the pre-filter in place.

6 After using the cleaner

6.1 Switching off the cleaner



1. Unplug the Power Cord from the electrical outlet.
2. If the machine is not cleaning as expected and the "Restricted Airflow light" is not illuminated, open the dust housing to ensure that the dust bag is not full, replace it if necessary. See also separate instructions for replacing the dust bag. Clean the bag housing if necessary.
3. Wind up the cord (starting from the machine inlet side).
4. Store the cord on the hook at the Dust lid cover and the hook at the handle.
5. Check the brush house. Remove any built-up carpet fibers or debris from the brush and the brush housing.
6. Store the machine indoors in a clean, dry place.

7 Further information

7.1 Repair and maintenance

Repairs, when required, should be performed by your Authorized Advance Service Center, who employs factory trained service personnel, and maintains an inventory of Advance original replacement parts and accessories.

Call the ADVANCE DEALER named below for repair parts or service. Please specify the Model and Serial Number when discussing your machine.

(Dealer, affix service sticker here.)



WARNING

- Always remove the electric plug from the socket before carrying out maintenance work on the machine.

7.2 Guarantee

Our general conditions of business are applicable with regard to the guarantee.

Unauthorised modifications to the appliance, the use of incorrect accessories, spare parts and cleaning chemicals in addition to using the appliance in a way other than for the intended purpose exempt the manufacturer from any liability for the resulting damage.

7.3 Specifications

		VU500 12 INCH	VU500 15 INCH
Voltage	V/Hz	110-120/50-60	110-120/50-60
Rated Power	W	1000	1000
Protection class (electrical)		I 	I 
Sound Pressure Level	dB(A)	69	69
Total weight both	lbs/Kg	19,5/8,9	20,7/9,5
Total weight without cord	lbs/Kg	17,6/8,0	18,9/8,6

USA
Nilfisk-Advance Inc.
14600 21st Avenue North
Plymouth, MN 55447-3408
Tel.: (763) 745 3500
Fax : (763) 745 3718

Canada
Nilfisk-Advance Canada
240 Superior Boulevard Mississauga,
ON L5T 2L2
Tel.: 905-564-1149
Fax: 905-564-1030



Advance

www.advance-us.com